

Installation Manual

ADA Wall Frame Adjustable


Z000000386

Released 11/09/2016

Assembly

Step 1: Glide Assembly - ADA Wall Style Frame


- a. Assemble a thread-in glide into the insert in each of the four (6) legs.



Step 2: Frame Assembly


- a. Using 3/8"-16 x 3 3/4" hex head cap screw, 3/8-16 Lock Nut and 3/8" washers, assemble the seat support leg to the main support frame.

Note: Use outside holes, no adjustment.




- b. Attach support leg using 3/8-16 x 3-1/2" cap screw button head and 3/4-16 lock nuts.

Note: Place button head on inside of leg.



- c. Attach table angle to main support using 1/4-20 x 2.0" hex head screws and 1/4-20 kep nut. Attach cantilever to main support using 1/4-20 x 5/8" machine screws on the bottom and 1/4-20 x 3/4" hex head cap screws with a 1/4-20 kep nut on the top.



Step 3: Fasten Glides to the Floor

- a. Rotate glides so that the mounting hole is pointing towards the center of the booth.
- b. With a pencil, mark the hole location on the floor using the holes in the glide.
- c. Turn the glide away 90 degrees from its current position to expose the mark on the floor.
- d. Using a hammer drill and a 1/4" masonry bit, drill a 1 1/4" deep hole on the pencil mark.
- e. Place a plastic anchor in the hole and then rotate glide back so its hole lines up with the plastic anchor in the floor.

